

BF-PP

Looking from beam pipe

PWR

GND

always use
second hole
from top

SMEC-PP

SM
Bottom
Panel

last 1 channel
not used

A18L01

D18L01

A18L23

D18L23

A18L45

D18L45

A33L01

A33L23

A33L45

D33L05

DCS

